



PROFESSOR MOTOR

Thanks for purchasing the “CLUB RACER SUPER PRO” Model Electronic Controller PMTR2128

Intended application : HO, 1/32 & 1/24 Home & Club Racing from low powered stock through highly modified motors

This model features the following high quality features

- **Recommended operating voltage range 14 to 19 volts DC**
- Wired for **POSITIVE** polarity tracks (not for direct connection to home set power base)
- Variable Braking System (high quality 25 Ohm wire wound pot to vary brake performance)
- Variable Sensitivity System (high quality single wire wound pot to adjust sensitivity setting)
- Electronic “Platinum Series” transistor design with ultra wide range of control
- Fault tolerant ultra robust circuit design to protect against overload or short circuit damage
- Internal handle-protected aluminum heat sink
- Fully functional in 2 wire (non-brake) application (some HO & 1/32)
- Power pilot light system for power and polarity indication
- Integral blast relay system for better performance at WOT (wide open throttle)
- Extra long, heavy duty 13 gage super flexible, high temp silicone controller leads
- Solid copper alligator clips with color coded vinyl insulating boots
- High impact polycarbonate plastic molded handle, Stainless steel hardware throughout
- Low friction silver alloy wiper button with ultra hard nickel plated contact surface

Use & Care Instructions

- Brake Adjust – Adjust the red color-coded knob with the white line “up” for MAXIMUM braking effect. Turn that knob counter-clockwise to reduce braking effect.
- **IMPORTANT TECH TIP !** – When finished racing turn the brakes always to the “full on” position to allow the circuit breaker in the system to protect the brake potentiometer if accidentally misconnected when next racing
- Sensitivity Adjust - Adjust the silver color-coded knob with the white line “up” for MINIMUM sensitivity. Turn that knob counter-clockwise to increase the sensitivity (provides more power to the car on initial application of the throttle).
- **Caution ! : Regular maintenance is required** to keep the controller contacts clean and free from foreign objects & debris. Failure to properly clean, lube and maintain the contacts will cause the controller to fail, will allow the car to be driven without the throttle being depressed and can result in the wire wound pot used for brake control becoming short circuited & damaged. Please take this warning seriously and follow this process to keep the contacts clean & properly lubricated :
 1. Remove the front half of the controller case by loosening the three bolts
 2. Clean all debris from the nickel-plated contacts with a Q-Tip and lighter fluid
 3. The sliding contacts MUST be CAREFULLY lubricated to reduce contact wear and provide a smoother controller action. To lube, do so as follows :
 - a. Place a **SMALL** amount of Super Lube PTFE lube on the end of a Q-Tip & apply to the nickel contacts in the area where the silver alloy contact travels
 - b. Cycle the trigger a few times
 - c. Use a Q-Tip with lighter fluid to remove any excess lube outside of the area where the contacts meet (remove 90% of the lube you just applied)
 - d. Examine the contact area to insure that cotton fibers from the Q-Tip are removed and that residual lube is minimal & barely visible
 4. Repeat this cleaning / lube process on a frequent basis (every 1-2 weeks) for best results.
- Periodic Maintenance – lube the trigger pivot bushing with plastic compatible oil

For technical information, questions or the latest catalog of available service parts and upgrades please visit us on the World Wide Web : www.professormotor.com